







**Start** 



Make a small start in the seam you wish to open with a normal air chisel. If there is already something to lever against you may not need to do this.

Use jaws



Start the jaws in the seam and open a small amount carefully

## **Small bites**



Take small bites, close the tool and move it deeper into the seam.



**Bigger** 



Once properly located you can start to pull the joint open.

Open the joint



Now you can take big pulls and the jaws will not slip or tear the metal.

Move along



Close the tool, move it along the joint and re-engage

Opened joint



The end result, less than 2 minutes from start to finish.