


ERLP Fırdöndü Mapa



**Uygulama
videosunu izle**

| Art.No. | Model | Ölçüler (mm) | | | | | | | Ağırlık (kg) |
|------------|-------------|--------------|-----|------|----|----|------|----|--------------|
| | | L | M | B | D | C | H | W | |
| 2903 32 08 | ERLP-M8-10 | 15 | M8 | Ø 27 | 10 | 20 | 63 | 52 | 0.2 |
| 2903 32 10 | ERLP-M10-10 | 20 | M10 | Ø 27 | 10 | 20 | 63 | 52 | 0.2 |
| 2903 32 12 | ERLP-M12-10 | 19 | M12 | Ø 38 | 15 | 31 | 91.8 | 73 | 0.8 |
| 2903 32 16 | ERLP-M16-10 | 24 | M16 | Ø 38 | 15 | 31 | 91.8 | 73 | 0.8 |